$s(q_k) = \sqrt{\frac{1}{n-1}} (q_k - Q)$

Adapter INA 5580





INA 5580

- The INA 5580 is an adapter from the NSG 5500 and allows fine-tuning the pulse to get the correct output during the clamp calibration.
- Includes the necessary BNC to N-type connectors, adapters and the necessary cables
- Designed for use with the CIP 9136, also available from Teseq

